



Windows Device Compatibility List

*	Approach® X40	Approach® S20	Approach® G7	Approach® G8	D2™	D2™ Bravo	epix™	Edge® 1000/Edge® 1000 Explore	Edge® 820/ Edge® 820 Explore	Edge® 520	Edge® 25	eTrex® Touch 35 APAC	fēnix® Chronos	fēnix® 5	fēnix® 5S	fēnix® 5X	fēnix® 3	fēnix® 2	fēnix®	Forerunner® 935	Forerunner® 920XT	Forerunner® 735XT	Forerunner® 630	Forerunner® 620	Forerunner® 235	Forerunner® 230	Forerunner® 225	Forerunner® 220	Forerunner® 35	Forerunner® 25	GPSMAP® 276Cx	GPSMAP® 64s	Index™ Smart Scale	Oregon® 750t	Rino® 7xx	tactix®	vivosmart® HR	vivoactive®	vivofit® 3	vivofit® 2	vivofit®	vivomove®	vivosmart® HR+	vivoactive® HR	vivosmart® 3	vivosmart®	vívokl™	
Nokia Lumia 635	✓	✓	✓ ¹	✓	✓ ^{1,2}	✓	*	✓ ¹	✓ ¹	✓ ¹	✓	✓	✓ ¹	*	*	*	✓	✓	*	*	✓	✓	X	✓ ¹	*	X	X	✓ ¹	✓ ¹	✓ ¹	✓	X	✓ ¹	✓ ¹	*	✓ ^{1,2}	✓	✓	✓	*	✓	✓ ^{1,2}	✓ ¹	*	X	*		
Nokia Lumia 640	*	*	✓	*	*	✓	✓	✓	*	*	*	*	*	*	*	*	*	*	*	*	✓	✓	✓	X	*	*	X	X	*	*	*	*	X	*	*	*	*	*	*	*	✓	✓	*	*	✓	*		
Nokia Lumia 640XL	✓	✓	*	✓	*	✓	*	✓ ¹	✓ ¹	✓ ¹	✓	✓	✓ ¹	*	*	*	✓	*	*	*	*	✓ ²	✓	X	*	✓	X	X	✓ ¹	✓ ¹	✓ ¹	✓	X	X	✓ ¹	*	✓ ^{1,2}	✓	✓	✓	✓	✓	✓ ^{1,2}	✓ ^{1,2}	*	✓	*	
Nokia Lumia 830	✓	✓	✓ ¹	✓	*	✓	✓	✓ ¹	✓ ¹	✓ ¹	✓	✓	✓ ¹	*	*	*	✓	*	*	*	✓	✓ ²	✓	X	✓ ¹	*	X	X	✓ ¹	✓ ¹	✓ ¹	✓	X	X	✓ ¹	*	✓	✓	✓	✓	✓	✓	✓ ^{1,2}	✓ ^{1,2}	*	✓	*	
Nokia Lumia 909	✓	✓	*	✓	*	*	*	✓ ¹	✓ ¹	✓ ¹	✓	✓	✓ ¹	*	*	*	*	✓	*	*	*	✓	*	*	✓	*	*	*	✓ ¹	✓ ¹	✓ ¹	✓	*	✓ ¹	✓ ¹	*	*	*	✓	*	✓	✓ ^{1,2}	✓ ^{1,2}	*	*	*		
Nokia Lumia 929Icon	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	✓	*	✓	X	✓	*	X	X	*	*	*	✓ ¹	X	*	*	*	*	*	*	*	*	✓	✓	*	*	✓	*	
Nokia Lumia 930	✓	✓	✓ ¹	✓	*	✓ ¹	✓ ²	X	✓ ¹	✓ ¹	✓	✓	✓ ¹	*	*	*	✓	*	*	*	*	✓	✓ ¹	X	✓	*	X	X	✓ ¹	✓ ¹	✓ ¹	✓	X	X	✓ ¹	*	✓ ^{1,2}	X	✓	*	*	*	*	✓	✓ ^{1,2}	✓ ¹	*	*
Nokia Lumia 950	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	X	*	*	*	X	X	*	*	*	*	X	*	*	*	*	*	*	*	*	*	*	*	*	*	
Nokia Lumia 950XL	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	X	*	*	X	X	*	*	*	*	X	*	*	*	*	*	*	*	*	*	*	*	*	*	*	
Nokia Lumia 1020	*	*	*	*	X	✓	*	✓	*	*	*	*	*	*	*	*	*	*	*	*	*	✓	*	*	X	*	*	X	X	*	*	*	*	X	*	*	*	✓	*	*	*	✓	*	*	*	✓	*	
Nokia Lumia 1520	✓	✓	*	*	*	✓	*	✓ ¹	✓ ¹	✓ ¹	✓ ¹	✓	✓ ¹	*	*	*	✓	*	*	*	*	✓	✓	X	*	*	X	X	✓ ¹	*	✓ ¹	*	X	X	✓ ¹	*	✓ ^{1,2}	✓	✓	✓	*	✓	✓ ^{1,2}	✓ ^{1,2}	*	*	*	

¹ - Pairing may timeout without finding the Garmin device, requiring additional attempts to pair Garmin devices. Once initial pairing has been completed connections between the device and this phone are stable.
² - Garmin Connect Mobile may notify you that your phone or Garmin device need to be restarted when an unstable BLE connection occurs, or when the app cannot reconnect to a previously connected BLE device.
³ - Reconnection times between this phone and Garmin devices are longer than other Garmin device and phone combinations.
X - Device and phone combination did not pass our internal tests. The phone and device may work together, but will likely require regular Bluetooth troubleshooting.
* - Device and phone combination have not been tested.

Is your phone not listed? Garmin will attempt to keep this list up to date with the most popular Smartphones that feature Bluetooth Smart technology however it will be possible that a particular model may work but not be listed as compatible.

If your Smartphone is not listed above, it is possible for it to be compatible if it meets the following requirements:

- Bluetooth 4.0 capable